

OpenCBM 0.4.2 Users Guide

Michael Klein, nip@c64.org , Spiro Trikaliotis, cbm4win@trikaliotis.net , Wolfgang Moser d81.de , Arnd Menge [arnd\(at\)jonnz\(dot\)de](mailto:arnd(at)jonnz(dot)de) ,
2007-11-18

This document describes the OpenCBM package, a Linux kernel module and Windows kernel mode driver, and a few user space support programs to control and use serial devices as used by most Commodore (CBM) 8-bit machines.

Contents

1 Overview	3
1.1 Introduction to OpenCBM	3
1.2 Supported operating systems	4
1.3 Supported CBM hardware	4
1.4 Cables	4
2 News/Changelog	6
3 Upgrading OpenCBM from an older installation	8
4 Installation	9
4.1 Installing OpenCBM on Linux (cbm4linux)	9
4.1.1 Compile-time configuration	9
4.1.2 Compilation	9
4.1.3 Loading the module	9
4.1.4 Troubleshooting	10
4.1.5 Device access	10
4.1.6 Runtime configuration	11
4.1.7 Security considerations	11
4.2 Installing OpenCBM on Windows (cbm4win)	12
5 Checking if the installation is complete	13
6 Uninstallation/Removal	14
6.1 Uninstalling OpenCBM on Linux (cbm4linux)	14
6.2 Uninstalling OpenCBM on Windows (cbm4win)	15
7 Utilities	15
7.1 instcbm (Windows only)	16
7.1.1 instcbm invocation	16